
## RIO DP101/DP102 CAST IRON PUMP/VALVE COMBINATION



- \* Rugged Cast Iron Construction
- \*Interchangeable Parts
- \*Optional Mounting
- \*Optional Air shift actuation
- \*High performance




◆ Dump Pump/Valve Ordering Specification



#### **TECHNICAL DATA**

Model series	Maximum psi	GPM @1800 RPM		MAXIMUM SPEED
		2"	2.5"	
DP101	2500	39	48	2400
DP102	2500	39	48	2400

#### DP101/102




RIO offers a complete line of rugged cast iron pump / valve combination for the dump truck and trailer industry. Units are available for SAE-B PTO mounting (DP102) or remote drive shaft mounting (DP101). Units are supplied with full flow adjustable main relief valves to protect the pump and cylinder from overloading and shock loads. A three position valve assembly controls the raising, holding and lowering of a single acting cylinder, control valve can be cab operated using mechanical cable actuation or air shift control. Installation can be either 2 line or three line type using the sleeve supplied see page E4.2.

# RIO DP101/DP102 CAST IRON PUMP/VALVE COMBINATION




#### 2-line installation

One line to cylinder, one line to the reservoir. For intermittent operation only.




#### **Spool in Neutrol Position:**

Oil recirculates internally.



**Spool in Raise Position:** 

Oil is routed through work port to raise the cylinder.




**Spool in Lower Position:** 

Oil flows from the cylinder through the relief valve to return to tank.


#### 3-line installation

One line to cylinder, two lines to the reservoir. For continuous or intermittent operation.




#### **Spool in Neutrol Position:**

Oil circulates through the pump and returns to tank



#### **Spool in Raise Position:**

Oil is routed through work port to raise the cylinder.




#### **Spool in Lower Position:**

Oil flows from the cylinder through the bottom port and returns to tank.

Note: Three line installation is recommended whenever possible by installing the sleeve supplied in the inlet port and connecting the optional return line to tank. This configuration maintains a lower operating temperature and a return line filter can be installed to filter return flow. Two line installations are for intermittent operation only.

# RIO DP101/DP102 CAST IRON PUMP/VALVE COMBINATION






ITEM	DESCRIPTION	ITEM	DESCRIPTION	ITEM	DESCRIPTION
1	SHAFT SEAL	11	VAVLE HOUSING	20	CAP SCREWS
2	SHAFT END COVER	12	VALVE SPOOL	21	RELIEF VALVE ASSEMBLY
3	SHAFT RING SEALS	13	"O" RINGS	22	CAP CREWS
4	ROLLER BEARINGS	14	RETAINER RINGS	23	SLEEVE(OPTIONAL)
5	POCKET SEALS	15	SNAP RINGS	24	WASHERS
6	THRUST PLATES	16	VALVE CAP	25	CHECK ASSEMBLY
7	KEY	17	POPPET SPRING	26	SNAP RING
8	DRIVE HAFT&GEAR	18	STEEL BALL	27	SPACER
9	GASKET SEALS	19	DETENT RETAINER	28	RETAINER
10	GEAR HOUSING	19A	LOCAL WASHER		


# RIO DP101/DP102 CAST IRON PUMP/VALVE DIMENSIONS




## RIO DP101

GEAR WIDTH: 2.0" 2.5" WEIGHT(lbs): 66 69









### **RIO DP102**

GEAR WIDTH: 2.0" 2.5" WEIGHT(lbs): 68 71



## RIO C101/C102 AIR SHIFT





#### Air Shift Installation Instructions

- The Air shift mounts on IFP C101 / C102 Dump pumps in place of the detent end cap
- Prepare work area by assuring a clean work environment for assembly & disassembly of the Dump pump spool valve

#### Prepairing Pump / Valve spool for air shift kit installation

- Remove snap ring and washer from valve spool
- Remove the detent cap, spring and ball from the valves end cap
- Remove four(4) cap srews and slide detent cap from the spool
- \*\*DO NOT REMOVE "O " RING FROM VALVE HOUSING\*\*

#### Installinon of air shift kit

- Remove retainer cap
- Remove snap ring / spring retainer / spring / washer
- Slide piston assembly from the cylinder body
- Remove setscrew from piston assembly using 1/4"hex wrench
- Grease and slide Retainer Cap over valve spool with flat face of cap facing the spool body
- Assemble snap ring / spring retainer / spring / washer on piston
- Slide piston over valve spool and align and insert set screw attaching the piston to the spool
- Grease piston and O Rings
- Slide cylinder body over the piston assembly making sure not to damage the O Rings
- Secure the assembly using the 4 cap screws supplied